




Schema explodată Slefuitor pereti / tavan SP 901



Schema esplosa Slefuitor pereti / tavan SP 901



Schema esplosa Slefuitor pereti / tavan SP 901



DP-900C spare parts list

No.	Product code	Description in English	Qty
1	BT0090001	connecting shaft	1
2	BT0090002	semi-circular key 3x3.5x10	1
3	BT0090003	oil seal	1
4	BT0090004	seal ring	1
5	BT0090005	collar $\Phi 28 \times \Phi 24 \times 2$	1
6	BT0090006	small bearing cover	1
7	BT0090007	deep groove ball bearing 6901z	1
8	BT0090008	tapered gear	1
9	BT0090009	locking shaft	3
10	BT0090010	seal ring $\Phi 24 \times \Phi 20 \times 2$	1
11	BT0090011	pressing plate for dust collection cover	1
12	BT0090012	dust collection cover	1
13	BT0090013	cross head screw M4*12	6
14	BT0090014	cross tapping screw M4*12	6
15	BT0090015	gear box	1
16	BT0090016	screw pin	2
17	BT0090017	flexible sleeve	1
18	BT0090018	big rubber sleeve	2
19	BT0090019	horn damping	2
20	BT0090020	rotor spring	1
21	BT0090021	wool felt	1
22	BT0090022	middle cover	1
23	BT0090023	rotor	1
24	BT0090024	dust ring	1
25	BT0090025	ball bearing 607 RS	1
26	BT0090026	anti-wind ring	1
27	BT0090027	slotted tapping screw ST4*55	2
28	BT0090028	round buckle	1
29	BT0090029	stator	1
30	BT0090030	sleeve 2#	1
31	BT0090031	motor housing	1

No.	Product code	Description in English	Qty
32	BT0090032	brush holder	2
33	BT0090033	carbon brush	2
34	BT0090034	slotted tapping screw ST3*10	4
35	BT0090035	slotted tapping screw	2
36	BT0090036	back cover	1
37	BT0090037	washer $\phi 4$	4
		spring washer $\phi 4$	4
		screw M4*20	4
38	BT0090038	pressing block on motor housing	1
Round sanding pad			
39	BT0090039	screw M6X14	1
40	BT0090040	washer $\phi 6$	1
41	BT0090041	sanding pad	1
42	BT0090042	output shaft	1
43	BT0090043	flat key 3x3x8	1
44	BT0090044	oil seal	1
45	BT0090045	collar $\phi 22$	1
46	BT0090046	deep groove ball bearing 6900 RS	1
47	BT0090047	slotted tapping screw ST4*12	8
48	BT0090048	brush segment	1
49	BT0090049	sanding pad cover	1
50	BT0090050	cover board for sanding pad cover	1
51	BT0090051	stop pin	1
52	BT0090052	reset spring	1
53	BT0090053	locking pull knob	1
54	BT0090054	locking plate	1
55	BT0090055	locknut ST4*12	1
56	BT0090056	spring leaf	3
57	BT0090057	front cover	1
58	BT0090058	compression spring	4

No.	Product code	Description in English	Qty
59	BT0090059	cross screw ST4*12	8
60	BT0090060	end gear	1
61	BT0090061	circlip	1
62	BT0090062	deep groove ball bearing	2
63	BT0090063	collar Φ28	1
64	BT0090064	needle bearing	1
65	BT0090065	connecting gear shaft	1
66	BT0090066	deep groove ball bearing	1
67	BT0090067	big bearing cover	1
68	BT0090068	screw M4*12	5
Delta sanding pad			
69	BT0090069	cross screw M4*8	3
70	BT0090070	delta sanding pad	1
71	BT0090071	aluminum cover	1
72	BT0090072	circlip Φ26	1
73	BT0090073	deep groove ball bearing	1
74	BT0090074	eccentric shaft	1
75	BT0090075	flat key 3x3x8	4
76	BT0090076	eccentric block	1
77	BT0090077	circlip	1
78	BT0090078	soft segment	3
79	BT0090079	rubber column	3
80	BT0090080	delta sanding pad cover	1
81	BT0090081	anti-rotating pin	1
82	BT0090082	compression spring	5
83	BT0090083	anti-rotating pin cover	1
84	BT0090084	cross tapping screw ST4*12	5
85	BT0090085	cross head screw M4*10	6
86	BT0090086	cross screw ST4*12	8
87	BT0090087	seal ring	8
88	BT0090088	washer Φ14*Φ4.3*1	8
89	BT0090089	base for delta sanding pad	1

No.	Product code	Description in English	Qty
90	BT0090090	collar Φ28	1
91	BT0090091	locking plate	1
92	BT0090092	locknut M4	1
93	BT0090093	locking pull knob	1
94	BT0090094	reset spring	1
95	BT0090095	stop pin	1
96	BT0090096	oil seal	1
97	BT0090097	collar Φ22	1
98	BT0090098	deep groove ball bearing	1
99	BT0090099	spring leaf	3
100	BT0090100	front cover	1
101	BT0090101	needle bearing	1
102	BT0090102	gear 1#	1
103	BT0090103	gear 2#	1
104	BT0090104	flat key 3x3x8	2
105	BT0090105	connecting gear shaft	1
106	BT0090106	deep groove ball bearing	1
107	BT0090107	deep groove ball bearing	1
108	BT0090108	big bearing cover	1
109	BT0090109	screw M4*10	5
110	BT0090110	tightening ring	1
111	BT0090111	350 hose	1
112	BT0090112	small bearing cover	2
113	BT0090113	small rubber cover	1
114	BT0090114	right handle stand	1
115	BT0090115	φ28 connector	2
116	BT0090116	φ28 plastic soft pipe	1
117	BT0090117	connector	1
118	BT0090118	left handle stand	4
119	BT0090119	cross tapping screw ST4*14	26
120	BT0090120	electric sensor	4
121	BT0090121	left main handle	1

No.	Product code	Description in English	Qty
122	BT0090122	electric capacity	2
123	BT0090123	control plate	1
124	BT0090124	switch	1
125	BT0090125	cable pressing plate	1
126	BT0090126	cable sleeve	1
127	BT0090127	cable	1
128	BT0090128	double accesses	1
129	BT0090129	wire	1
130	BT0090130	front rubber sleeve	1
131	BT0090131	seal ring	1
132	BT0090132	round pin	1
133	BT0090133	back rubber sleeve	1
134	BT0090134	round pin	1
135	BT0090135	round pin	1
136	BT0090136	back rubber sleeve plate	1
137	BT0090137	Lock wrench	1
138	BT0090138	brace	1
139	BT0090139	Double sheath	2
140	BT0090140	spring wire	1
141	BT0090141	front rubber sleeve plate	1
142	BT0090142	double accesses	1
143	BT0090143	cross tapping screw ST4*14	26
144	BT0090144	right main handle	1
145	BT0090145	aluminium pipe insert	1
146	BT0090146	back screw nut	2
147	BT0090147	left sub-handle	1
148	BT0090148	single access	1
149	BT0090149	right sub-handle	1
150	BT0090150	adjustable ring	1
151	BT0090151	adapter	1