



Schema explodata Pompa Airless PAZ 6331i si PAZ 6335i







315100	Control board assembly	315108	Bridge
315101	Digital electronic spray control display	315109	Tie wrap
315102	Control board cover with label	315110	Circuit board
315103	ON/OFF switch	315111	Screw
315104	Pressure regulator	315112	Gasket
315105	Fuse	315113	EMI filter
315106	Insulated rubber tape 1	315114	Insulated rubber tape 2
315107	Screw		




315200	Housing assembly
315201	Front Cover
315202	Slider assembly
315203	Drive assembly
315204	O-ring
315205	Gear/crankshaft assembly
315206	1 st stage gear
315207	Baffle assembly
315208	Screw




31300	Fluid pump assembly
31301	Retainer
31302	Spacer
31303	Upper packing
31304	Pump block
31305	Fitting
31306	Pressure sensor
31307	Return tube
31308	Nut
31309	Piston rod
31310	Lower packing
31311	Upper housing
31312	O-ring
31313	Outlet valve ball
31314	Outlet valve seat
31315	Lower housing
31316	Hose
31317	Suction tube
31318	Suction filter




35300	Fluid pump assembly
35301	Retainer
35302	Spacer
35303	Upper packing
35304	Pump block
35305	Fitting
35306	Pressure sensor
35307	Return tube
35308	Nut
35309	Piston rod
35310	Lower packing
35311	Upper housing
35312	O-ring
35313	Outlet valve ball
35314	Outlet valve seat
35315	Lower housing
35316	Hose
35317	Suction tube
35318	Suction filter



315401	Filter housing
315402	Pump filter
315403	O-ring
315404	Fitting
315405	Spring
315406	Prime/spray valve retainer
315407	Prime/spray valve handle
315408	Cam base
315409	Groove pin
315410	Prime/spray valve stem
315411	Prime/spray valve housing
315412	Gasket
315413	Fitting
315414	Outlet connector
315415	Pressure gage
315416	Connector
315417	O-ring
315418	Gasket
315419	Nut



315500	Motor housing assembly	315509	Fan
315501	Long screw	315510	Motor cover
315502	Nut	315511	Carbon brush
315503	Magnetic cylinder	315512	Cap
315504	Capacitor	315513	Retaining clamp
315505	Motor	315514	Screw
315506	Baffle assembly	315515	Wire retaining screw
315507	Thrust washer	315516	Power wire
315508	White washer		



315600	Cart assembly
315601	Screw
315602	Cart
315603	Pneumatic wheel
315604	Handle assembly