


# Explozie piese de schimb PC60-L

Major components			
NO.	PART NO.	DESCRIPTION	QTY
1	500001	Protective frame	1
2	500002	Clamp	1
3	500003	Engine	1
4	500004	Hex bolt M12*55	2
5	500005	Bigger flat washer $\varnothing$ 12.5	2
6	500006	Rubber coupling for handle	2
8	500008	Lower half of foldable handle	1
9	500009	Upper half of foldable handle	1
10	500010	Flat washer $\varnothing$ 10	2
11	500011	Locknut M10	2
12	500012	Flat washer $\varnothing$ 10	2
13	500013	Hex bolt M10*35	2
14	500014	Horned bolt	2
15	500015	Throttle lever	1
16	500016	Throttle cable	1
17	500017	Bigger flat washer $\varnothing$ 12	2
18	500018	Bigger flat washer $\varnothing$ 8	1
19	500019	Spring washer $\varnothing$ 8	1
20	500020	Hexagonal bolt M8*25	1
21	500021	Fit screw M10*35	2
22	500022	Flat washer $\varnothing$ 10(Optional )	2
23	500023	Oil seal	1
24	500024	Wheel bracket	1
25	500025	Outer circlip $\varnothing$ 17	2
26	500026	Flat washer $\varnothing$ 17	4
27	500027	Wheel	2
28	500028	Plate for engine mounting	1
29	500029	Dust-proof plate	1
30	500030	Clutch assembly $\varnothing$ 16	1
31	500031	Flat key 5*30	1
32	500032	Belt cover	1
33	500033	Pulley, driven	1
34	500034	Flat key 8*16	1
35	500035	Belt	1



36	500036	Case cover / shut-off	1
37	500037	Bearing 6209	2
38	500038	Vibrating plate	1
39	500039	Ecc. Rotary shaft	1
40	500040	Case cover for pulley	1
41	500041	Spring washer $\varnothing$ 5	8
42	500042	Socket bolt M6*25	8
43	500043	Shock absorber for vibrating plate	4
44	500044	Foldable Handle Assy	1
45	500045	Trolley wheel Assy	1
46	500046	Paper cushion	2

